Zum-BT-TWS 2 Wireless Buds™

TWS True Wireless Bluetooth® Earbuds With Wireless Charging Case



USER GUIDE English



CONTENTS

Features	1
Overview	2
Charging	2
Powering On Stereo Mode, Method 3	2
Reconnecting	3
Using Only One Bud	3
Powering Off	3
Using Voice Commands	
Left/Main and Right/Second Buds	
Charging	
Notes	
Table of Ear Bud States	
Warranty	

FEATURES

Thanks for choosing Zum-BT-TWS-2 Wireless Buds[™]. It's important to read this User Manual: it will help you connect the Buds and pair with your Bluetooth[™] device

- Bluetooth 5
- · Case charges wirelessly.
- · Charges earbuds in case when not in use.
- 2 Mics per bud allow noise reduction to minimize background noise.
- · Voice assistant calling feature (ie. Siri)
- IPx7 waterproof (up to 1m for 30 min).
- · Qualcomm aptX® for quality audio
- · Wireless for freedom of movement.
- Pairs with your Bluetooth® devices, such as smartphones and tablets.
- Music playback time up to 12 hours. Standby time 130 hours, recharge time 1.5 hours.
- Sweat resistant, use them for exercising/working out.

Spracht®

OVERVIEW





- Red and blue LED indicator
- Multi Function Button (MFB)
- Microphone
- 4 Charging contacts (other side)
- **6** Charging Indicator LED
- Wireless charging base
- Micro USB charging jack (underside, center)

CHARGING

Charging the Buds

IMPORTANT Before using the Buds for the first time, make sure to fully charge the Buds. Place the Buds in the case, making sure that the contacts engage on both Buds. The Red LED on the Buds will blink while they are charging. When the Red LEDs on the Buds turn off, charging is complete. Charging should take roughly 1½ hours. Note that red LEDs should be on for both Buds if they are charging properly.

NOTE

- Close the cover on the case while the Buds are charging. This will help assure the contacts are making a solid connection.
- 2. LED case status. While the Buds are out of the case, the LED on the case will be off. When then Buds are placed in the case the White LED on the front of the case will go on and indicate the charged status of the case.

White LED flashing every 2 seconds - low battery in the case

White LED flashes 3x every 2 seconds - battery in the case is charged

White LED stays on - full battery in the case

White LED is off - case battery needs charging

When you remove the Buds from the case, the white LED on the case will go out after 1 minute.

NOTE: The battery is recyclable. Keep the battery (inside the case) away from heat sources such as a fire, in direct sunlight, or a closed car in summer. Before charging, confirm that the charging port is dry.

Charging the Case

When you put the Buds in the case, the White LED on the front of the case will indicate the battery status in the case (see above). If charging is indicated, you have 2 options for charging.

Using the USB cable

- 1. Connect the Micro-USB end into the case's Micro-USB jack. The jack is located on the underside of the case.
- 2. Connect the USB end into a charging source such as a PC/Mac, or other 5V USB charger.

Charging will take about 1½ hours.

Using a Wireless Charger

- 1. Connect your Wireless Charger to a power source. You may not need to plug in the charger if it has a built in battery.
- 2. Place the Charging Case, with or without the Buds, in the center of the charger. The White LED will show:

White LED flashes - battery is charging

White LED solid on - charge is complete

Charging will take a little longer than via USB. If the Buds are in the charging case, they will charge also.

Using the Earbuds

Wearing

- 1. Choose the right size ear tips for your wearing comfort.
- 2. Make sure the Buds are in the correct ear: R in the right ear and L in the

left ear.

The extension on the Buds will point downwards if they are correctly positioned.

Use

The Buds can be used together for stereo mode, or individually.

USING ONLY ONE OF THE BUDS

- 1. Turn on the Bluetooth® device you want to pair, and navigate to the Bluetooth pairing function.
- Take the Buds out of the case: they will turn on automatically. If for some reason the Buds are off, press the MFB (center of the Buds) for about 3 sec until the White LEDs flash and the Buds say "Power on". They should now be on.
- 3. The Buds should enter TWS pairing mode automatically. The Red and White LEDs in the Buds will flash slowly and alternately Red and White. If you had previously paired with a Bluetooth device, they will re-pair. If the Buds powered off prior to pairing, press the MFB for 8 sec, and release when the White and Red LEDs flash alternately. You will hear "Pairing".
- 4. On your phone's Bluetooth list you should see Zum-TWS-L or Zum-TWS-R. Choose the one you want to pair. You should hear "Phone is connected".
- 5. The phone will show a pop-up dialog "Headset would like to pair with your phone". If you click "Pair", the second Bud will connect to the phone. The Buds will be able to switch primary/secondary functions.
- 6. To power off, press the MFB for about 5 sec until you hear "Power off". The Buds will automatically power off if you put them in the charging case.
- 7. If you only want to use one Bud, just pair the L or R side and turn off the other side.

IMPORTANT: If you use just one bud in Single Ear Mode and then want to use both Buds at the same time in Stereo Mode later, please note that you must pair the LEFT/Main Bud first. If you pair the Right Bud first, the Left one will not connect afterwards in Stereo Mode. You will need to start over by deleting the 2 Bluetooth® entities in your phone/tablet (you will see Zum-TWS listed twice. Delete both). Turn off the Buds and restart them.

Start the pairing process from the beginning.

NOTE: 1. When the earbuds are idle and not connected to a Bluetooth device, they will turn off automatically after 5 minutes to save power.

2. Pairing mode lasts for 2 minutes. If the earbuds are not paired with an

2. Pairing mode lasts for 2 minutes. If the earbuds are not paired with any Bluetooth device after 2 minutes, the earbuds will enter standby mode, which lasts 3 minutes. They will turn off automatically after the standby mode ends.

FUNCTIONS WITH ONE EARBUD

1. MUSIC

FUNCTION	STATUS OF EARBUDS	L	R	PROMPT TONE
Play	Pause	Double-click MFB	Double-click MFB	Ding
Pause	Playing music	Double-click MFB	Double-click MFB	Ding
Previous song	Playing music	Press Left MFB 2s	N/A	Ding
Next song	Playing music	N/A	Press Right MFB 2s	Ding
Volume up	Playing music	N/A	Click Right MFB	Ding
Volume down	Playing music	Click Left MFB	N/A	Ding

Spracht®

2.CALLING

FUNCTION	STATUS OF EARBUDS	L	R	PROMPT TONE
Cancel calling	Calling	Click MFBn	Click MFB	Two Tone _ High Falling after Ding
Answering	Incoming call ringing	Click MFB	Click MFB	Ding
Reject	Incoming call ringing	Press MFB 2s	ress MFB 2s	Two Tone _ High Falling
End calling	During a call	Double-click MFB	Double-click MFB	Two Tone _ High Falling after Dang tone
Voice switch to phone	During a call	Press MFB 2s	Press MFB 2s	Two Tone _ High Falling
Voice switch to earbuds	During a call	Press MFB 2s	Press MFB 2s	Two Tone _ Low rising
Active SIRI	Connected device	N/A	Triple-click MFB	"Voice dial"
Volume up	During a call	N/A	Click MFB	Ding
Volume down	During a call	Click MFB	N/A	Diang

USING BOTH BUDS - STEREO MODE

- 1. Turn on the Bluetooth® device you want to pair, and navigate to the Bluetooth pairing function.
- Turn on either earbud and connect it with your Bluetooth device, then power on the other earbud: they will connect with each other automatically.
- 3 Primary/Secondary switch: When the primary earbud is successfully paired with the phone, the phone will Pop-up a dialog: "Headset would like to

- pair with your phone". If you click "pair", the secondary earbud will also be paired with the phone. Primary-secondary switching function will be on.
- 4. In the following cases, the secondary earbud can automatically switch and connect to the mobile phone, so you continue to use it:
 - (1) In the process of use, if the primary earbud is automatically turned off due to low power, the secondary earbud will be automatically connected to the mobile phone.
 - (2) When the primary earbud is disconnected from the mobile phone at a distance, the secondary earbud will be automatically connected to the mobile phone.
 - (3) When the primary earbud is put into the charging case, the secondary earbud will be automatically connected to the mobile phone.

FUNCTION WITH TWO EARBUDS CONNECTING TO CELLPHONE MUSIC

FUNCTION	STATUS OF EARBUDS	L	R	PROMPT TONE
Play	Pausing	Double-click MFB	Double-click MFBn	Ding
Pause	Playing music	Double-click MFB	Double-click MFBn	Ding
Previous song	Playing music	Press Left MFB about 2s	N/A	Ding
Next song	Playing music	N/A	Press Right MFB about 2s	Ding
Volume up	Playing music	N/A	Click Right MFB	Ding
Volume down	Playing music	Click Left MFB	N/A	Ding

7 Spracht®

CALLING

FUNCTION	STATUS OF EARBUDS	L	R	PROMPT TONE
Cancel calling	Calling	Click MFB	Click MFB	Two Tone_ High Falling after Ding
Answering	Incoming call ringing	Click MFB	Click MFB	Ding
Reject	Incoming call ringing	Press MFB about 2s	Press MFB about 2s	Two Tone _ High Falling
End calling	During a call	Double-click MFB	Double-click MFB	Two Tone_ High Falling after Ding
Voice switch to phone	During a call	Press tMFB about 2s	Press MFB about 2s	Two Tone _ High Falling
Voice switch to earbuds	During a call	Press MFB about 2s	Press MFB about 2s	Two Tone _ Low rising
Active SIRI	Connected device	N/A	Triple-click MFB	"Voice dial"
Volume up	During a call	N/A	Click MFB	Ding
Volume down	During a call	Click MFB	N/A	Ding

EARBUD PAIRING/CONNECTING

If the two Buds cannot connect with each other:

- 1. Turn off two earbuds individually (don't turn them off by putting them into the charging case).
- 2. Clear the pairing list: Choose one of the earbuds. First, enter the pairing mode. Then hit the MFB button 5 times, while the Red LED and White LED turn on for 1 second. The pairing list will be cleared when you hear a prompt tone. Do the same thing with the other Bud.
- 3. The earbuds will enter TWS pairing mode automatically when they are

turned on (indicator light status: Red and White LEDs flash slowly). After successful connection, the primary earbud (L) will say "Pairing" after a "ding" tone. The LEDs will alternately flash Red and White, waiting to be paired with your phone. The secondary earbud(R) will sound a 'Ding' and the white LED will flash 2 times every 5 seconds.

POWERING OFF

When using two earbuds, if either the Left or Right turns off, the other will also turn off. The earbuds will have corresponding indicator lights and prompts when they turn off.

Remarks:

- In calling mode, both Buds are functional, but you will hear the call only in the Bud connected to the cellphone.
- When using two earbuds to talk, the transfer audio operation is on the Primary earbud. In other words, when the Left earbud is primary, press the Left MFB about 2s to transfer audio; when the Right earbud is Primary, press Right MFB button about 2s to transfer audio.

BATTERY STATUS

When the earbuds are connected to an IOS device, it will display the battery status of the earbuds on the device. When the earbuds is low on power ,the battery indicator will turn red and show a depleted battery icon. The Buds will also give an audio prompt to charge your headset.





FACTORY RESET

When the earbuds are in the pairing mode, click the MFB 5 times. The factory reset is indicated when the Red LED and Blue LED turns on for 1 second. At the same time, you will hear a prompt tone and turn off.

Remarks:

- After factory reset, the paired list of the two Buds and mobile phone will be deleted. The Bud does not automatically reconnect with the mobile phone or the other Bud after turning on.
- After factory reset, when the Bud turns on again, it will automatically enter
 the TWS pairing mode (Red and White LEDs flash slowly alternately). The
 two earbuds will be paired automatically. After TWS connection, the Left Bud
 will continue to wait for pairing with the mobile phone (Red and White LEDs
 flash quickly alternately).

CARE AND MAINTENANCE

Recommendations.

- Keep the Buds dry. They are not meant for strenuous exercise. Try to keep sweat away from the Buds.
- Keep away from direct sunlight or heat. High temperatures will shorten the life of electronic devices, destroy the battery or distort certain plastic parts.
- Don't expose to cold areas. It may damage the internal circuit board.
- · Don't try to disassemble the Buds.
- Try not to drop them on the floor or other hard surfaces. The internal circuit board might get damaged.
- Don't use strong chemical products or detergent to clean the Buds.
- · Don't scratch the surface with sharp things.

FAQs

- What does it mean when red LED flashes slowly four times a minute? Battery is low, needs to be recharged.
- 2. Why is the red LED off when charging?
 - a) The charging case may not have enough power to charge the headset. Please charge the charging case.
 - b) Make sure the metal contacts of the earbud and charging case are free of obstacles.
 - c) The battery may be low. Please charge the battery for 30 minutes, until the red LED goes on.
- 3. Why can't I hear the sound on the headset?
 - a) Make sure the volume is not too low or muted;
 - b) Make sure the headset connects with the mobile phone correctly;
 - c) Make sure the distance between the headset and the cell phone is in Bluetooth range (around 30' max).

- 4. Why can't I hear the sound clearly on the headset?
 - a) Make sure the mobile phone is in a strong signal area;
 - b) Make sure the headset is in the available range, and nothing is in the way of the signal.
- 5. Why aren't the pause/play, last/next song not working when playing music?

Make sure your Bluetooth device supports AVRCP (Audio/Video Remote Control profile).

Specifications

Bluetooth version

Bluetooth profiles

Operating distance
Working time(one earbud)

Working time(two earbuds)

Standby time Charging time for earbud Charging time for case Times charging case can

charge the earbuds
Charging input for case

Weight

Dimensions

Bluetooth V5.0

HFP, HSP, A2DP and AVRCP

10 meters

Up to 10 hours(maximum volume)

Up to 13 hours (50% volume)
Up to 9 hours (maximum volume)

Up to 12 hours (50% volume)

About 130hours About 1.5 hours About 1.5 hours More than 2 times

USB charging: DC5.0V 500mA

One earbud:6.5g Charging case:44.2g Earbud: 42*22.4*23mm

Charging case: 63*30.3*47.8mm

Warranty Information

Spracht warrants its products against defects or malfunctions in material and workmanship under normal use and service, with the exceptions stated below. This warranty lasts for one year from the original date of purchase. Coverage terminates if you sell or otherwise transfer the product. In order to keep this warranty in effect, the product must have been handled and used as prescribed in the instructions accompanying the product.

Spracht shall (at its option) repair or replace a defective unit covered by this warranty, or shall refund the product purchase price. Repair, replacement with a new or reconditioned unit, or refund, as provided under this warranty, is your exclusive

remedy. This warranty does not cover any damages due to accident, misuse, abuse, or negligence. Spracht shall not be liable for any incidental or consequential damages. Some states do not allow limitation or exclusion of incidental or consequential damages, so the above limitation or exclusion may not apply to you.

To make a warranty claim, the purchaser must obtain a return authorization number (RA) from Spracht (serial number and purchase date required), and then return the product to Spracht at purchaser's expense. A copy of the original dated receipt or shipping document must accompany the product. To obtain a return authorization, see "Warranty" on our website at www.spracht.com, send an e-mail to support@spracht.com, or contact us at:

Spracht

974 Commercial Street, Suite 108

Palo Alto, CA 94303 USA

Ph: 650-215-7500 Fx: 650-485-2453

For repair or replacement of a failed product, allow 4 to 6 weeks for processing and shipment. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state

Spracht 974 Commercial Street, Suite 108 Palo Alto, CA 94303 www.spracht.com

© Copyright 2020 Spracht®. All rights reserved. Spracht® and the logo, and Zum-BT-TWS-2 Buds are trademarks and registered trademarks of Spracht®. Any other trademarks are properties of their owners.