

Warranty

Spracht® warrants its products against defects or malfunctions in material and workmanship under normal use and service, with the exceptions stated below. This warranty lasts for one year from the original date of purchase. Coverage terminates if you sell or otherwise transfer the product. In order to keep this warranty in effect, the product must have been handled and used as prescribed in the instructions accompanying the product. Spracht® shall (at its option) repair or replace a defective unit covered by this warranty, or shall refund the product purchase price. Repair, replacement with a new or reconditioned unit, or refund, as provided under this warranty, is your exclusive remedy. This warranty does not cover any damages due to accident, misuse, abuse, or negligence. Spracht shall not be liable for any incidental or consequential damages.

Some states do not allow limitation or exclusion of incidental or consequential damages, so the above limitation or exclusion may not apply to you. Implied warranties of merchantability and fitness for a particular purpose are limited in duration to the duration of this warranty. Some states do not allow limitations on how long an implied warranty lasts, so the above limitation may not apply to you. To make a warranty claim, the purchaser must obtain a return authorization number (RA) from Spracht® (serial number and purchase date required), and then return the product to Spracht at purchaser's expense. A copy of the original dated receipt or shipping document must accompany the product. To obtain a return authorization, see Warranty on our website www.spracht.com, e-mail info@spracht.com, or contact us at:

Spracht®
974 Commercial Street, Suite 108
Palo Alto, CA 94303 USA
Tel: 650-215-7500 Fax: 650-485-2453

©2019 Spracht®. All Rights Reserved.



Aura USB Mic™ Digital USB Microphone MIC-2010



QUICKSTART GUIDE English Only



Aura USB Mic™ Features

Thanks for purchasing the Aura USB Mic™! Just set the mic on the table, plug into the USB port of your PC / Mac and your microphone is ready for Skype, Zoom, and other VoIP calls. Record audio for YouTube videos, too. Perfect Huddle Room microphone.

- Plug and play: Compatible with Windows 10, 8, 7, Vista and XP, and Mac OS X
- Omni-directional for 360° coverage
- Voice pickup range is 6' to 9'
- 6' (1.8m) USB cable, USB 2.0
- Echo and noise cancellation

Aura USB Mic™ Specifications

- Plug and play: Compatible with Windows 10, 8, 7, Vista and XP, and Mac OS X
- Aluminum Alloy with metal mesh cover
- Omni-directional for 360° coverage
- Sample rate of 48KB 16 bit
- Frequency response 100Hz - 16KHz
- Max sound level: 110dB
- Signal to Noise ratio: >60dB
- Sensitivity: 47±3dB
- Weight 4.8oz (137g)
- Dimensions 2.74" dia x .6" h (70mm dia x 15mm h)



Setting up Aura USB Mic™

1. Plug the USB cable into your computer's USB port.
2. Find the Sound settings on your computer. Its location will depend on your computer's OS, whether Mac or Windows.
3. You should see (LCS) USB Audio Device. Select it for Input.
4. You can test the levels to make sure there is enough volume being captured, and increase the volume as needed.
- 5 That's it! You can make VoIP calls, such as Skype, and Zoom, and Bluejeans using the drivers for the app. You don't need any drivers for the microphone.

Quick Debugging

The microphone is plugged in but you're not seeing levels or hearing sound.

- Make sure the USB cable is in a USB port on the computer not in a hub. There may not be enough power for the microphone.
- Confirm you selected the microphone as the input device in your computer's sound preferences.
- If you have the microphone set as the input device, make sure the volume is set up enough, and that the sound is not muted.
- If you are using the microphone for recording, confirm the recording software supports USB input.

Can the USB cable made to reach further using a USB extension cable?

- This is not recommended since attaching another cable will affect sound quality and volume.